



SWADLING

BRASSWARE

INSTALLATION INSTRUCTIONS

Engineer Deck Mount 3 Hole Basin Mixer

82000

STANDARD
(Spout Length)

LONG
(Spout Length)

STANDARD

11RDX

13RDX

TALL

31RDX

33RDX



IMPORTANT INSTALLATION INFORMATION




- Before Installation, please check all parts against the parts list on the back page of this booklet.
- Make sure that the parts are undamaged and that their finish is as expected.
- Should you find a faulty or damaged part, please be in touch with our Customer Services Team immediately using the contact details below.
- Any claim for faulty or damaged parts will require the affected part to be returned to Swadling Brassware for inspection and testing.
- No claim for damaged parts or issues with a product finish will be accepted after the product has been installed.

Swadling Brassware, Churchward Road, Yate, Bristol, BS37 5PL




Telephone: 01454 322888 **Email:** techsupport@swadlingbrassware.co.uk

DIMENSIONS

SPOUT VARIANTS	
A	B
168mm (LONG)	237mm (TALL)
120mm (STANDARD)	137mm (STANDARD)



INSTALLATION



Hole
for taps
Min Ø28
Max Ø32

Hole
for taps
Min Ø28
Max Ø32

HOT
1/2" BSP

COLD
1/2" BSP



PARTS LIST

SEE SPOUT LENGTH
TABLE

SPOUT LENGTH VARIANTS	
PART No.	LENGTH
SB0195	120mm (STANDARD)
SB0196	168mm (LONG)

TUBE HEIGHT VARIANTS	
PART No.	HEIGHT
SB0089	110mm (STANDARD)
SB0099	210mm (TALL)

SB0286
(AERATOR)

SEE TUBE
HEIGHT
TABLE

SB0093

SB1206

1415

SB0263

SB0052

SB0264

SB0096

SB0242

SB0065

1517 A SILVER

SB0100

SB0074

1274 A SILVER

SB0092

SB0095

SB0261

SB0035

SB0066

SB0029

SB0030

1457 A SILVER

SB0028

SB1206

1415

GENERAL INSTALLATION TIPS

- Handle parts carefully and consider wearing gloves for living and brushed finishes.
- Only use water or soapy water to clean visible parts.
- Where silicone is required, only use neutral cure silicone.
- Chemicals should be kept away from this product. Splashes and sometimes vapours from household cleaning fluids, marble sealers and grout haze removers can cause damage.